



Stopping at Nothing to Get You Stopped

MATCO mfg
2361 S 1560 West
Woods Cross, UT 84087
801-335-0582
801-335-0581 (F)
www.matcomfg.com

MH TUBELESS KIT INSTALLATION NOTES



1 Reference photo of o-ring on wheel half prior to installation. The radius area just outside the bolt circle should be inspected for nicks or scratches. Any nicks or scratches found should be polished smooth as they can provide a leak path around the o-ring when in the final seated position



2 Lubricate o-ring with silicon or petroleum gel and slide o-ring onto wheel half. It may be installed all the way to bead seat.



3 O-ring installed resting on bead seat. The radius area of the wheel half where the o-ring will seat in the final position may be lubricated with silicon or petroleum gel.



4 Insert the other wheel half into the tire



5 Insert wheel half with o-ring into tire and mate with opposite half. O-ring is still installed on bead seat.



6 Bolt wheel halves together with .31-18x.875 bolts installed in every other bolt hole.



7 Compress tire side walls slightly and slide o-ring into groove between wheel halves.